



Water distiller Instruction for use




Prepare collection bottle

To remove any “new” smell from the plastic collection bottle - fill it with warm (not boiling) water, add a tablespoon of baking soda (bicarbonate) and leave overnight. Rinse well before use. Never use boiling water in the collection bottle.

Insert activated carbon sachet

Soak the activated carbon teabag sachet in a cup of warm water for a little while, then fold it in half and insert it into the plastic nozzle. Reassemble the nozzle and put it into the collection bottle, line up with the spout on SmartStill.

An activated carbon sachet can be used for 3-4 distillations or up to one month. Replace regularly for best filter effect.



Filling and starting distiller

Remove the whole top from SmartStill, fill liquid into the boiling chamber. Do not fill above the filling line mark. Put the whole top back on again and make sure it seals properly. Make sure that you have read and understood the safety advice, then connect to mains power.

The fan should go on immediately. If not, press RESET button.

It will take around one hour to heat up the liquid, then the distilled liquid will start to drip through the activated carbon, into the collection bottle.


The whole process will take around 3-4 hours (1 hour heating up, 2-3 ours of distilling). When you want to stop distilling, simply unplug the power cord. If you leave it on, the distiller will automatically switch off at the end of distillation.

Safety advice

- Place SmartStill on a flat, heat tolerant and waterproof surface. Ensure good ventilation and no heat sources nearby.
- Unplug power cord when not in use.
- Never immerse any SmartStill part in water, keep outside dry.
- SmartStill is not intended for use by children.
- Never remove the top when SmartStill is on. Wait at least 20 minutes after distillation until you remove the top.
- Do not pour boiling water into the plastic collection bottle.
- Do not use SmartStill near open fire, flames or cigarettes.

Maintenance

- Never use abrasive cleaners or brushes on your SmartStill.
- Rinse the inside of the boiling chamber after each distillation.
- Remove deposits in the boiling chamber regularly. Fill with water, add one sachet of SmartPart Residue Cleaner and switch on SmartStill untill boiling. Turn off and rinse out.



Legal disclaimer

Although SmartStill is perfectly suited for home distillation of alcohol, you must only do so in countries where it is legal. You must further obtain all necessary permits or licenses and pay all alcohol duties required.